



Telecaster 3 Way Switch Wiring Diagram



 = Ground