


Gibson / Epiphone SG Wiring Diagram



⏏ = Ground