


## PRS 2 Pot Push & Pull Wiring Diagram



⏏ = Ground