


Fender Telecaster with 4 Way Switch Left Handed Wiring Diagram 250k Reverse Taper Pots



 = Ground