

Telecaster Left Handed Wiring Diagram

2 x 250 Reverse Taper Pots

47 Cap

3 Way Switch

