

Gibson / Epiphone Les Paul Classic Wiring Diagram

All Push Pulls in Down Position – Standard Les Paul Wiring.
Neck Volume Up – Splits Neck Humbucker to Single Coil.
Bridge Volume Up – Splits Bridge Humbucker to Single Coil.
Neck Tone Up – Bridge and Neck Humbuckers Pure Bypassing.
Bridge Tone Up – Neck and Bridge Humbuckers Out of Phase

