

Telecaster SH 3 Way Toggle Switch Left Handed Wiring Diagram

500k Reverse Taper Pots

