


PRS 2 Pot Wiring Diagram 500k Pots



⏏ = Ground