


## Jackson HH Series / Parallel Wiring Diagram

500k Pots

5 Way Switch



### Switching

Position 1: Bridge Humbucker in Series

Position 2: Bridge Series / Neck Series in Parallel.

Position 3: Neck Humbucker in Series

Position 4: Bridge (screw split) / Neck (slug split), Parallel, Hum Cancelling.

Position 5: Bridge (screw split)