

Telecaster HH 3 Way Toggle Switch Left Handed Wiring Diagram

2 x 500 Reverse Taper Pots

22 Cap

3 Way Toggle Switch

