


## Telecaster HH 3 Way Switch Wiring Diagram

2 x 500 Pots  
22 Cap  
3 Way Switch



⏏ = Ground